

इंटरनेट

मानक

### Disclosure to Promote the Right To Information

Whereas the Parliament of India has set out to provide a practical regime of right to information for citizens to secure access to information under the control of public authorities, in order to promote transparency and accountability in the working of every public authority, and whereas the attached publication of the Bureau of Indian Standards is of particular interest to the public, particularly disadvantaged communities and those engaged in the pursuit of education and knowledge, the attached public safety standard is made available to promote the timely dissemination of this information in an accurate manner to the public.

“जानने का अधिकार, जीने का अधिकार”

Mazdoor Kisan Shakti Sangathan

“The Right to Information, The Right to Live”

“पुराने को छोड़ नये के तरफ”

Jawaharlal Nehru

“Step Out From the Old to the New”

IS 10096-3 (2002): Recommendations for Inspection, Testing and Maintenance of Radial Gates and Rope Drum Hoists, Part 3: After Erection [WRD 12: Hydraulic Gates and Valves]



“ज्ञान से एक नये भारत का निर्माण”

Satyanarayan Gangaram Pitroda

“Invent a New India Using Knowledge”



“ज्ञान एक ऐसा खजाना है जो कभी चुराया नहीं जा सकता है”

Bhartrhari—Nitiśatakam

“Knowledge is such a treasure which cannot be stolen”



BLANK PAGE



भारतीय मानक

त्रिज्य गेट और रज्जु ड्रम उच्चालकों के निरीक्षण,  
परीक्षण एवं रख-रखाव की सिफारिशें

भाग 3 लगाने के बाद

(दूसरा पुनरीक्षण)

*Indian Standard*

RECOMMENDATIONS FOR INSPECTION,  
TESTING AND MAINTENANCE OF  
RADIAL GATES AND ROPE DRUM HOISTS

PART 3 AFTER ERECTION

(*Second Revision*)

ICS 93.160

© BIS 2002

**BUREAU OF INDIAN STANDARDS**  
MANAK BHAVAN, 9 BAHADUR SHAH ZAFAR MARG  
NEW DELHI 110002

## FOREWORD

This Indian Standard (Part 3) (Second Revision) was adopted by the Bureau of Indian Standards, after the draft finalized by the Hydraulic Gates and Valves Sectional Committee had been approved by the Water Resources Division Council. Noting lack of adequate systematic information on procedures for inspection, testing and maintenance of radial gates and their hoists after erection, the Hydraulic Gates and Valves Sectional Committee decided that a set of recommendations on this subject be drawn up for reference and guidance of the personnel engaged in these duties. This standard has accordingly been prepared to provide guidelines for radial gates.

This standard has been published in parts. Part 1 deals with inspection, testing and assembly at manufacturing stage. Part 2 deals with inspection, testing and assembly at the time of erection. Part 3 deals with inspection, testing and maintenance after erection.

This standard (Part 3) was first published in 1982. In the first revision in 1992, the provision in respect of inspection was elaborated in detail. This second revision of standard had been taken up to incorporate the knowledge gained during use of this standard. In this revision an additional clause has been added regarding maintenance of gates to be operated in winter.

There is no ISO standard on the subject. This standard has been prepared taking into consideration the practices prevalent in the field in India.

The composition of the Committee responsible for the formulation of this standard is given in Annex A.

For the purpose of deciding whether a particular requirement of this standard is complied with, the final value, observed or calculated, expressing the result of a test or analysis, shall be rounded off in accordance with IS 2 : 1960 'Rules for rounding off numerical values (*revised*)'. The number of significant places retained in the rounded off value should be the same as that of the specified value in this standard.

*Indian Standard*

**RECOMMENDATIONS FOR INSPECTION,  
TESTING AND MAINTENANCE OF  
RADIAL GATES AND ROPE DRUM HOISTS**

**PART 3 AFTER ERECTION**

*( Second Revision )*

**1 SCOPE**

This standard (Part 3) lays down the recommendations for inspection, testing and maintenance of radial gates and their rope drum hoists after erection.

**2 REFERENCE**

The Indian Standard given below contains provisions which through reference in this text, constitute provisions of this standard. At the time of publication, the edition indicated was valid. All standards are subject to revision, and parties to agreements based on this standard are encouraged to investigate the possibility of applying the most recent edition of the standard indicated below:

<i>IS No.</i>	<i>Title</i>
7718 : 1991	Recommendation for inspection, testing and maintenance of fixed wheel and slide gates ( <i>first revision</i> )

**3 GENERAL**

**3.1** Drain holes in the horizontal girders and arms should be checked so that they do not get clogged with silt causing accumulation of water in the horizontal girders and arms.

**3.2** Rope drums, pulleys and rope connection should be checked.

**3.3** Functioning of the limit switches, interlocking devices, indication lamps, etc, should be checked for proper working.

**3.4** The operating systems of the gate should be checked for their proper functioning.

**3.5** Where stoplogs are provided upstream of radial

gates, they should be maintained as per recommendations contained in IS 7718.

**4 INSPECTION**

**4.1** Periodical inspection of gate installations should be carried out to detect normal wear and tear, defects, if any. It should be done as and when necessary, but at least thrice in a year, one being prior to the onset of monsoon and one immediately after the monsoon and one at other times. The gates should be operated up and down several times to make sure that everything is in order.

**4.2** Inspection work may consist of visual inspection of exposed surfaces of embedded parts, such as sill beam, wall plate including seal seats, gate leaf, arms, trunnion assembly, trunnion girders, hoisting equipment, hoist supporting structures and checking of important dimensions. In cases of inaccessible parts, inspection may be necessary by other means like divers, etc.

**4.3 Inspection of Radial Gates**

No piece of equipment, however well designed and sturdy, will run efficiently unless it is well kept and maintained. Therefore the details of inspection to be done and the schedule of maintenance are given here.

**4.3.1 Periodical Inspection**

In order to detect normal wear and tear, defects, if any, periodical inspection of gate installation should be carried out. The periodical inspection of gates and hoists should be done as and when necessary, but at least thrice a year and corresponding to the periods when the water level in the reservoir is at its highest and lowest levels.

In short, premonsoon and post-monsoon inspections should be done and the following checks be exercised:

<i>Points to be Inspected</i> (1)	<i>Compliance</i> (2)
<b>I Inspection of yoke girder, thrust block, trunnion assembly and anchorage</b>	
1. Check Nuts and bolts :	
a) Trunnion assembly	Check for torque
b) Trunnion bracket to yoke girder	do
c) Nuts of horizontal and vertical anchorage	do
d) Trunnion pin lock plates	Check tightness
e) Check shear key if provided behind the trunnion bracket	Check for cracks
f) Nuts of the main tie rods	Check for tightness and torque
2. Check the weld between yoke girder and main ties	For soundness
3. Check whether yoke girder and thrust block is covered so that water does not accumulate in the slots.	Cover with 3 mm thick M.S. plates if not already covered
4. Check whether trunnion pin ends are covered with anticorrosive jelly	Cover it if not already covered
5. whether flexible sheath cover is provided to prevent entry of debris in the trunnion assembly	do
6. Check the welds of thrust block (with magnifying glass) (also ensure that the inside is concreted)	Check for cracks. Rectify accordingly
7. Check if the oval holes are free	Remove debris or other accumulated material
8. Check grease in trunnion assembly	Take steps for greasing after removal of dirt, if any
9. Check the flexible cover	Replace, if necessary and clean dirt from pin surface below the same
<b>II Arms</b>	
1. Check welding joints of arm to horizontal girder (with magnifying glass, preferably on joints/stiffeners)	Check for cracks: rectify accordingly
2. Check whether drain holes provided in the arms are clear of debris.	Clear them if choked up
3. Check nuts and bolts of arms to horizontal girder	Check for tightness and torque
<b>III Horizontal girder</b>	
1. Check welding of:	
a) Stiffeners of horizontal girders	Check for crack and other defects and rectify accordingly
b) Horizontal girder to stiffeners of skin plate	do
c) Locking arrangement brackets of skin plates	Check for weld crack
d) Check drain holes of horizontal girder	Clear them if choked and clean the debris accumulated regularly
<b>IV Skin plate assembly and rubber seals</b>	
1. Check the following welding joints:	
a) 'T' and skin plate and ribs	Check for crack and other defects and rectify, if necessary
b) Vertical joints of skin plate from upstream side and downstream side	
c) Check lifting bracket and lifting pins for its soundness	
d) Latching brackets to skin plate	Check welding with a magnifying glass and rectify, if required

<i>Points to be Inspected</i> (1)	<i>Compliance</i> (2)
2. The skin plate should be observed for pitting, scaling and corrosion on upstream side:	Scaling formation should be removed. Pitting should be filled with weld and grinded for finish. For corrosion clean it and apply paint.
a) Check the condition of side and bottom rubber seal corner joint and observe leakage	If condition is poor, replace same. Check the cause of undue wear also before replacement
b) All the nuts and bolts fixing rubber seal to skin plate	Check for wear and tear, tightness and replace, if required.
c) Check if there is any undesirable material in between seal and stainless steel plate, seal and seal base	Remove it (All debris should be periodically removed from the seal surface)
d) Check for deformation of seal	Study the cause of deformation and rectify it
e) Check soundness of cladding in case of cladded rubber seals	do
f) Check whether there is abnormal abrasion on seal seat	Study the cause of abrasion and rectify it
<b>V Sill beam and wall plates</b>	
1. Check the following joints :	
a) Wall plate to sill beam	Check for crack and other defects and rectify
b) Joints between two segments	Rectify the joints using proper welding rods and grind, as necessary
c) Stainless steel to structural steel	do
2. Check wall plate and sill beam for pitting and rusting and general conditions	Pitting is to be filled in by welding. Rusted portion should be painted after cleaning
<b>VI Guide roller</b>	
1. Check the roller for its movements and setting	Make the roller free. If jammed, clean and grease
2. Check the nuts and bolts of guide roller assembly	Check for wear and tear and tightness
<b>VII Latching arrangement</b>	
1. Check whether latching device functions well	Check the function by operating lever. Rectify the same if movement is not smooth
2. Check nuts and bolts and studs of locking devices	Tighten the bolts if required
3. Check the drain holes	Clean them if required
<b>VIII Wire ropes, hoist, pulleys, sheaves, etc</b>	
1. Check for following :	
a) Check condition of wire rope	If the condition is poor, then replace the wire rope and if 10 percent broken wires are within the length of one meter and more than 20 percent broken wire within the length of 10 m wire ropes should be replaced
b) Check pulley, sheave assemblies and sockets	Check the condition of pins and every year these should be removed, cleaned and refitted after lubrication
c) Check turn buckles	Check for rusting, jamming in the turn buckles, and check if the number of threads holding the rope are adequate
d) Check tension of wire ropes	Adjust both wire ropes for equal tension
e) Check if end of wire rope is properly fastened to drum	If found loose, tighten the studs provided for
f) Check for lubrication of wire ropes, if required	Lubricate ropes



<i>Points to be Inspected</i> (1)	<i>Compliance</i> (2)
<b>IX Gear train assembly</b>	
1. Check the following:	
a) Check the condition of gear and pinions	Check uneven wear and contact, adjust properly
b) Check position of gears and pinion	Bring them to correct position if found shifted to either side
c) Check shaft and couplings used for connecting drive unit and gear train	Visual inspection and coupling nuts to be checked
<b>X Drive unit</b>	
1. Check the following:	
a) Check the condition and functioning of electro-magnetic brake	Replace worn out liner, adjust brake shoes carefully, so that both the shoes hold the drum when supply is cut off or both the shoes should move out simultaneously if switched on. Brake drum and liner should always be free from grease, oil, etc
b) Check all electrical connection of hoist motor, brake, starter, limit switch, etc. Also check remote control systems, if provided	Check for loose connection, proper insulation (rats and crabs damage the insulation) Overload relay of the starter is to be adjusted, for correct position and should not be disturbed
c) Check the connecting arrangement from adjacent motor	
d) Check the condition of position indicator and all its accessories	Check for its proper function and rectify
e) Reduction gear box (worm reducer)	Check for smooth operation and check oil level
<b>XI Check nuts and bolts of the following :</b>	
a) Hoist frame } b) Drive unit }	Check for wear and tear and tightness
c) Gear boxes } d) Flange coupling }	Tighten if required or replace if undue wearing noticed
e) Bearing housing } f) Foundation bolts of hoist bridge }	Inspect for cracks in housing and replace, if needed check foundation bolts and tighten if required

#### 4.3.2 General

Inspection to check that:

- a) The gate operation should be trouble free and there should not be unusual sound.
- b) On load (that is, when there is water) there should be no undue vibrations in the gate and the structure.
- c) Observe the current drawn by motor at the time of lifting of gate. If any excessive current drawn is noticed, operation of hoist should be stopped immediately and reason for the same may be investigated for lubrication of various parts of gates and hoists and rectified.
- d) Check the supply voltage.
- e) Check the lubrication at various points.
- f) Check the condition of painting of various parts.

#### 5 TESTING

**5.1** The gate should be tested for its travel up and down to see that it moves smoothly without excessive sway throughout the length of travel.

**5.2** The operation should be trouble-free and there should not be any undue pressure or extra efforts when the gate is operated under no load condition.

Any extra current being taken by the motor should be taken note of.

**5.3** On load (that is, when there is water) there should be no undue vibrations in the gate and structure during operation of the gate. In case vibrations are noticed, the positions of gate openings and water levels should be noted and the reasons thereof should be investigated.

**5.4** Based on the inspection and testing, suitable remedial measures should be taken (*see 6*).

## 5.5 Trouble Locating Chart

<i>Trouble</i> (1)	<i>Probable Reasons</i> (2)
1. Gate does not rise	<ol style="list-style-type: none"> <li>1. No supply or low voltage (supply)</li> <li>2. Obstruction in rubber seals</li> <li>3. Obstruction in guide rollers</li> <li>4. Fault in electric motor</li> <li>5. Fault in wiring</li> <li>6. Blown out fuse</li> <li>7. Brake shoes jammed</li> <li>8. Wire rope broken</li> <li>9. Malfunctioning of electrical contacts due to any reason</li> </ol>
2. Gate vibrates or produces noise	<ol style="list-style-type: none"> <li>1. Lack of lubrication in trunnion and guide rollers</li> <li>2. Rope length not identical on both sides</li> <li>3. Lack of lubrication or fault in wire rope pulley sheave arrangements</li> </ol>
3. Motor does not function	<ol style="list-style-type: none"> <li>1. No supply</li> <li>2. Starter not in order</li> <li>3. Blown out fuses in switches</li> <li>4. Low voltage</li> <li>5. All fuses are not working</li> </ol>
4. Starter not working	<ol style="list-style-type: none"> <li>1. No supply to starter</li> <li>2. Fixed and moving contacts not in order</li> <li>3. Limit switch engaged</li> </ol>
5. Unusual sound	<p>Verify the spot and attend to the following:</p> <ol style="list-style-type: none"> <li>1. Mis-alignment of any particular component</li> <li>2. Shearing of connecting bolts and nuts</li> <li>3. Lack of lubrication</li> <li>4. Entry of any extraneous matter into guide roller assembly or pulley sheaves or trunnion assembly.</li> </ol>

## 6 MAINTENANCE

**6.1** The maintenance of radial gates and their hoists mechanism should be done regularly. Reference should be made to manufacturer's instructions for detailed maintenance and servicing of hoists. Proper record of inspection, testing and maintenance should be made by the project authorities.

**6.2** The following maintenance works should be attended to:

- a) Defective weld should be chipped out and it should be rewelded. Damaged nuts, bolts, rivets, screws, etc, should be replaced. Any pitting should be filled up by welding and finished by grinding, if necessary.
- b) The gate leaf, exposed embedded metal parts, hoists and hoist supporting structure, etc,

should be thoroughly cleaned and repainted when required. While deciding about repainting, the original painting system adopted should be kept in view.

- c) Trunnion bearing should be greased wherever required. Keeping trunnion bearings in perfect working condition is very important. All other bolted connections should also be checked for proper tightness.
- d) Bolts and trunnion bearing housing should be tightened wherever required.
- e) The seals of the gate should be checked for wear and tear and deterioration. These should be adjusted/replaced, as and when necessary.
- f) Wire ropes should be properly greased.
- g) Oil level in the worm reduction unit should

be maintained by suitable replenishment. Oil seals should also be replaced, if required. Lubrication of other parts of the hoists, such as chains, position indicators and limit switches should also be done.

- h) The stroke of the brake should be reset to compensate for lining wear. Worn out brake linings should be replaced in time.
- j) Flexible couplings should be adjusted, if required.
- k) Repairs and replacement of electrical relays and controls should be attended to.
- m) Maintenance of alternative sources of power, such as diesel generating sets and alternative drives wherever provided should be carried out.
- n) The list of essential spare parts to be kept available should be reviewed and updated periodically. The availability of essential spare parts should be ensured. The condition of spares should be checked periodically and protective coating given before use.
- p) Lubrication details:
  - 1) Grease — Multipurpose  
— Bearing grease

*Application points:*

- i) Pulley sheaves
- ii) Pulley brackets
- iii) Guide rollers
- iv) Trunnion assembly

- v) Rope drums
  - vi) Line shaft bearings
  - vii) Matching teeth of gear box assembly  
Once before rainy season or as required
- 2) Cardium compound

*Application points:*

Wire ropes

Once in every season after cleaning of wire ropes or as required

- 3) H.P. 90 Gear oil

*Application points:*

- i) Reduction gear box

Level up the gear box before operation

- 4) Mobil oil

*Application points:*

- i) All rubbing surfaces and oiling points
- ii) At points located in brass/metal bushes

Once/twice a year.

**6.3** In case of gates to be operated during winter, generally water leaking through water tight parts gets frozen and grows to be ice lumps. Chances are that such ice lumps adhere to the gate leaf or embedded parts causing troubles. Therefore in case of such gates following remedial measures shall be taken in addition to the maintenance work given in 6.2.

- a) Water leakage shall be prevented.
- b) Ice at gate leaf and embedded parts may be removed by the manual or by any anti-freezing method without damaging gate components.

## ANNEX A

(Foreword)

## COMMITTEE COMPOSITION

## Hydraulic Gates and Valves Sectional Committee, WRD 12

<i>Organization</i>	<i>Representative(s)</i>
In Personal Capacity (2047, Pocket 2, Sector D, Vasant Kunj, New Delhi 110 070)	SHRI N. VISHWANATHAN ( <i>Chairman</i> )
Bhakra Beas Management Board, Nangal	DEPUTY CHIEF ENGINEER EXECUTIVE ENGINEER ( <i>Alternate</i> )
Bharat Heavy Electricals Ltd, Bhopal	SHRI A.S. SRIVASTAVA SHRI S.R. RATHORE ( <i>Alternate</i> )
Central Water and Power Research Station, Pune	SHRI R. M. KHATSURIA SHRI R.M. SINNARKAR ( <i>Alternate</i> )
Central Water Commission, New Delhi	DIRECTOR (GATES - E&NE) DIRECTOR (GATES-NW&S) ( <i>Alternate</i> )
Cimmco Ltd, Bharatpur	EXECUTIVE PRESIDENT SR MANAGER (DESIGN) ( <i>Alternate</i> )
Gea Energy System (India) Ltd, New Delhi	SHRI K.C. BAHETY SHRI A. G. K. MURTY ( <i>Alternate</i> )
Haryana State Minor Irrigation (Tubewell), Chandigarh	SHRI S. P. GUPTA SHRI R. S. CHAUHAN ( <i>Alternate</i> )
Himachal Pradesh State Electricity Board, Sundernagar	CHIEF ENGINEER (DESIGN) DIRECTOR (PLNG) DESIGN CIVIL II ( <i>Alternate</i> )
Irrigation Department, Govt of Maharashtra, Nasik	SHRI V. C. SHELKE
Irrigation Department, Govt of Punjab, Chandigarh	CHIEF ENGINEER [RSDD] DIRECTOR (M&E) ( <i>Alternate</i> )
Irrigation Department, Govt of Uttar Pradesh, Roorkee	CHIEF ENGINEER (DESIGN) AND DIRECTOR SUPERINTENDING ENGINEER ( <i>Alternate</i> )
National Hydroelectric Power Corporation Ltd, Faridabad	SHRI A. K. SACHDEVA SHRI G. S. SHARMA ( <i>Alternate</i> )
Orissa Construction Corporation Ltd, Bhubhaneshwar	DIRECTOR [MECHANICAL] SENIOR MANAGER (DESIGN) ( <i>Alternate</i> )
Public Works Department, Government of Tamil Nadu, Chennai	SHRI M. DURAIRAJ SHRI T. KRISHNASWAMY ( <i>Alternate</i> )
Texmaco Ltd, Kolkata	SHRI S. R. SINHA SHRI UDAYAN BANERJEE ( <i>Alternate</i> )
Triveni Structurals Ltd, Allahabad	SHRI J. P. MISHRA SHRI B. P. SINGH ( <i>Alternate</i> )
Tungabhadra Steel Products Ltd, Bellary	SHRI G. S. ANNIGERI SHRI N. KANNAIAH NAIDU ( <i>Alternate</i> )
Water Resources Development Training Centre, Roorkee	PROF GOPAL CHAUHAN
BIS Directorate General	SHRI S.S. SETHI, Director & Head (WRD) [Representing Director General ( <i>Ex-officio</i> )]

*Member-Secretary*  
SHRI KULDEEP SIROHI  
Deputy Director (WRD), BIS

## Bureau of Indian Standards

BIS is a statutory institution established under the *Bureau of Indian Standards Act, 1986* to promote harmonious development of the activities of standardization, marking and quality certification of goods and attending to connected matters in the country.

## Copyright

BIS has the copyright of all its publications. No part of these publications may be reproduced in any form without the prior permission in writing of BIS. This does not preclude the free use, in the course of implementing the standard, of necessary details, such as symbols and sizes, type or grade designations. Enquiries relating to copyright be addressed to the Director (Publications), BIS.

## Review of Indian Standards

Amendments are issued to standards as the need arises on the basis of comments. Standards are also reviewed periodically; a standard along with amendments is reaffirmed when such review indicates that no changes are needed; if the review indicates that changes are needed, it is taken up for revision. Users of Indian Standards should ascertain that they are in possession of the latest amendments or edition by referring to the latest issue of 'BIS Catalogue' and 'Standards: Monthly Additions'.

This Indian Standard has been developed from Doc No. : WRD 12 (285).

### Amendments Issued Since Publication

Amend No.	Date of Issue	Text Affected

### BUREAU OF INDIAN STANDARDS

#### Headquarters :

Manak Bhavan, 9 Bahadur Shah Zafar Marg, New Delhi 110 002  
Telephones : 323 01 31, 323 33 75, 323 94 02

Telegrams : Manaksanstha  
(Common to all offices)

#### Regional Offices :

	Telephone
Central : Manak Bhavan, 9 Bahadur Shah Zafar Marg NEW DELHI 110 002	{ 323 76 17 323 38 41
Eastern : 1/14 C.I.T. Scheme VII M, V. I. P. Road, Kankurgachi KOLKATA 700 054	{ 337 84 99, 337 85 61 337 86 26, 337 91 20
Northern : SCO 335-336, Sector 34-A, CHANDIGARH 160 022	{ 60 38 43 60 20 25
Southern : C.I.T. Campus, IV Cross Road, CHENNAI 600 113	{ 254 12 16, 254 14 42 254 25 19, 254 13 15
Western : Manakalaya, E9 MIDC, Marol, Andheri (East) MUMBAI 400 093	{ 832 92 95, 832 78 58 832 78 91, 832 78 92
Branches : AHMEDABAD. BANGALORE. BHOPAL. BHUBANESHWAR. COIMBATORE. FARIDABAD. GHAZIABAD. GUWAHATI. HYDERABAD. JAIPUR. KANPUR. LUCKNOW. NAGPUR. NALAGARH. PATNA. PUNE. RAJKOT. THIRUVANANTHAPURAM.	